



Handheld Sound Meter Detector



Eco Driven Solutions®

Included in package

- Whisper DB Meter with Hydrophone
- Two D cell alkaline batteries
- Headphones

1. Install two D cell alkaline batteries (included)
 - a. Depress the release tab using a coin or screwdriver.
 - b. Slide the battery cover away from the probe tip to remove cover.
 - c. Insert D batteries according to illustration inside the battery compartment.
 - d. Replace the battery cover. Be sure to slide battery cover along the side rails until the release tab is engaged.
2. Turn meter on and prepare for use.
 - a. Long press the power button to turn meter On/Off. The battery indicator will illuminate while the meter is On.
NOTE: If battery indicator flashes, battery power is low and batteries should be replaced.
 - b. If needed, adjust meter sensitivity by swiping the touch pad up or down.
NOTE: Meter defaults to the last sensitivity setting when powered On.
3. Using meter
 - a. Place hydrophone in water near ultrasonic unit.
 - b. LED scale will illuminate with each pulse transmission from the ultrasonic unit.
 - c. Plug earphones into side of meter to listen to the ultrasonic transducer single, modulated for human hearing.
 - d. Check signal at multiple distances from ultrasonic unit.